









#	Steps	Process steps	Tool	Date/Time	Checklist																									
Process revision notes	Added 4th mask for patterning alumina. Added RIE for first metal layer. Need to test out thicker AZ3312 dark erosion against AZ435 MIF																													
Part 0: wafer prep Prepare wafer for oxide deposition, deposit insulating dielectric to isolate device from wafer																														
0.1	Start	6-inch prime (100)-Si wafers.																												
0.2	RCA Clean	10 min SC1, 5 min HF, 15 min SC2	Nano/RCA-Diffusion-L02																											
0.3	Deposit SiO2	300nm SiO2. Tube-oxidation(-Clean or -Flex)	Tube-Oxidation(-Clean or -Flex)																											
Part 1: Metal gate contacts Sputter W and dry etch to form source and drain contacts																														
																														
1.1	Sputter W	W 10nm (Ar 20sccm, 3mTorr, DC 100W, deposition time 133s, rotation ON, shutter delay 60s). 5 min 200 W presputter to clean target	Nano/Sputter-AJA-LL	2025/03/09 AM	<ul style="list-style-type: none"> <input type="checkbox"/> Take picture of wafer pre-deposition <input type="checkbox"/> Record chamber base pressure <input type="checkbox"/> Measure dep rate with QCM (#8 for W) - optional <input type="checkbox"/> Record P,V,I for spark, presputter, and sputter <input type="checkbox"/> Take picture post-deposition <input type="checkbox"/> Measure Rsheet with 4-point probe <p>dep time 133 s (10 nm) (3:15 layer time)</p> <table border="1"> <thead> <tr> <th></th> <th>strike</th> <th>precan</th> <th>predep</th> <th>dep</th> </tr> </thead> <tbody> <tr> <td>W</td> <td>203</td> <td>204 203 205</td> <td>102</td> <td>105 102</td> </tr> <tr> <td>V</td> <td>294</td> <td>323 315 318</td> <td>309</td> <td>291 291</td> </tr> <tr> <td>I</td> <td>687</td> <td>650 615 610</td> <td>539</td> <td>519 517</td> </tr> <tr> <td></td> <td>0.0</td> <td>2.00 7.50</td> <td></td> <td>0.00 2.00</td> </tr> </tbody> </table> <p>Rshunt = 105 Ω/□ (?? reading is 22.61 mV for 1 mA current)</p> <p>no particulates</p> 		strike	precan	predep	dep	W	203	204 203 205	102	105 102	V	294	323 315 318	309	291 291	I	687	650 615 610	539	519 517		0.0	2.00 7.50		0.00 2.00
	strike	precan	predep	dep																										
W	203	204 203 205	102	105 102																										
V	294	323 315 318	309	291 291																										
I	687	650 615 610	539	519 517																										
	0.0	2.00 7.50		0.00 2.00																										
1.2	Photolithography [Layer 1]	AZ3312 1 um recipe; MLA: 405 nm, 130 mJ/cm², 0 defocus. Invert design Develop in picoTrack: AZ726_spry_60sec. Design rules: Min metal width = 2 um Min spacing = 2 um	Nano/CoatDevelop-picoTrack, MLA150-AirAF or OptAF or WaferOnly	2025/03/09 PM	<ul style="list-style-type: none"> <input type="checkbox"/> Record dose, defocus <input type="checkbox"/> Record layer # from GDS file <input type="checkbox"/> Take picture in microscope after developing <p>v11, L1, inv 405 nm, 130 mJ/cm², 0 defc angle: -0.01</p>   <p>✓ little slightly worse resist center (from coating issue) or not, see wafer U, which exhibited the same problem but didn't have the discoloration</p>																									

#	Steps	Process steps	Tool	Date/Time	Checklist											
1.3	Dry etch W	Etch 10 nm W with Tung-sel 20nm/min. 30 nm etched in ~83 s. 10 nm etched in 27 s. Overetch fine	Plasmatherm-A-L06	2025/03/09 PM	[] Take picture before etch [] Take picture (in microscope) after etch. Make sure color is uniform everywhere, especially that SiO2 surface is smooth and visible.   											
1.4	Solvent resist strip	Soak in hot NMP for 10 minutes, then sonicate for 1 min. Rinse with acetone, IPA. Blow dry N2	Nano/Solvent-L06	2025/03/09 PM	[] Take pictures in microscope (particularly around litho test structures) after clean [] Rsheet with 4-point probe hot NMP 5 min + 1 min sonicate, still some resist 											
1.5	Electrical testing	Measure resistance of W resistors on bottom metal layer. Check for linearity and consistency with step 1.1	Nano/Probestation-Summit-11000	2025/03/09 PM	[] Compare resistance of meandered resistors with measurement of 4-point probe <p>AI</p> <table border="0"> <tr> <td>51 sq res:</td> <td>$\frac{IV}{10\mu A} \rightarrow 48.2 \Omega$</td> <td rowspan="3">→ kinda nonlinear, maybe bad probe? → tried again dipping harder, no luck</td> </tr> <tr> <td>101 sq res:</td> <td>$\frac{IV}{3.87\mu A} \rightarrow 25.6 \Omega$</td> </tr> <tr> <td>500 sq res:</td> <td>$\frac{IV}{82.2\mu A} \rightarrow 22.9 \Omega$</td> </tr> </table> <p>probing W plane: $\frac{IV}{16\mu A} \rightarrow contact must be good ...$</p> <p>D5</p> <table border="0"> <tr> <td>51 sq res:</td> <td>$\frac{IV}{350\mu A}$ → pretty linear</td> </tr> <tr> <td>101 sq res:</td> <td>$\frac{IV}{350\mu A}$</td> </tr> </table>	51 sq res:	$\frac{IV}{10\mu A} \rightarrow 48.2 \Omega$	→ kinda nonlinear, maybe bad probe? → tried again dipping harder, no luck	101 sq res:	$\frac{IV}{3.87\mu A} \rightarrow 25.6 \Omega$	500 sq res:	$\frac{IV}{82.2\mu A} \rightarrow 22.9 \Omega$	51 sq res:	$\frac{IV}{350\mu A}$ → pretty linear	101 sq res:	$\frac{IV}{350\mu A}$
51 sq res:	$\frac{IV}{10\mu A} \rightarrow 48.2 \Omega$	→ kinda nonlinear, maybe bad probe? → tried again dipping harder, no luck														
101 sq res:	$\frac{IV}{3.87\mu A} \rightarrow 25.6 \Omega$															
500 sq res:	$\frac{IV}{82.2\mu A} \rightarrow 22.9 \Omega$															
51 sq res:	$\frac{IV}{350\mu A}$ → pretty linear															
101 sq res:	$\frac{IV}{350\mu A}$															
1.6	Plasma ash resist strip	Remove any residual resist with O2 plasma slow-strip-10min (Barrel-Thierry)	Nano/Asher-Barrel-Thierry or TergeoPro-Strip or Chuck-ESI		[] Inspect in microscope after clean, use a fab-wipe on the microscope stage <i>Skipped</i>											





Part 2: Alumina gate dielectric
ALD deposition of gate dielectric

#	Steps	Process steps	Tool	Date/Time	Checklist
2.1	Deposit ALD Al2O3	15nm Al2O3. Recipe: Al-TMA-H2O-200C (25 ms pulse, 10 s hold). 20 preconditioning cycles. 150 deposition cycles. Place dummy Si pieces on top of wafer. Measure with Filmetrics-F20, Ellipsometer-Semilab-SE2000, or Film-Sense Ellipsometer.	Nano/ALD-Ozone or ALD-AllPurpose		
				2025/03/09 PM	<ul style="list-style-type: none"> [] Take picture of chamber before deposition (with Palacios tablet) [] Record thickness of SiO2 on dummy chip before [] Place dummy chips around wafer edge [] Take picture of wafer before deposition [] Take picture of wafer after deposition [] Take picture of chamber after deposition (with Palacios tablet) [] Record thickness of SiO2+Al2O3 on dummy chips after  <p>P @ 200mbar N₂ : 0.16 Torr valve pulse purge ^{max press} 3 / 25ms / 10s / ~1.0 Torr 1 / 25ms / 10s / ~0.8 Torr</p> <p>dummy SiO₂ thickness: 1.406 nm</p> <p>15.60 nm (0.910 R²) → 15.68 (0.915 R²) → 15.64 nm avg 104 Å / cyc 15.54 nm (0.913 R²) ↓ 15.73 nm (0.914 R²)</p>
Part 2b: Optional via opening Etch vias in Al2O3 gate oxide to allow connections between metal layers					
		 <p>Mask 2 (*optional) ALD Al2O3 TMAH wet etch</p>			
2.2	Photolithography [Layer 2]	AZ3312 2 um recipe; MLA: 405 nm, 130 mJ/cm ² , 0 defocus. Design rules: Allow 1 um overetch on each side. Min spacing 5 um Min via width 2 um	Nano/CoatDevelop-picoTrack, MLA150-AirAF or OptAF or WaferOnly	2025/03/11 PM	<ul style="list-style-type: none"> [] Record rotation, scaling, shearing [] Record dose, defocus [] Record layer # from GDS file <p>AZ3312 1 μm recipe NOC PEB, bypass developer v12, L2, no invert Dose 130 mJ/cm² 440 lines Def. 0 Rot. -0.021 radial scal 1 / 1 shear 0</p>

#	Steps	Process steps	Tool	Date/Time	Checklist
2.3	Etch Al2O3	AZ435 MIF, 750s (slight overetch for 150A at 0.23A/s). dip in DI 3 times, rinse under flowing DI. Dry with N2 gun. Develop will finish in about 50 s	Nano/Develop-L08	2025/03/11 PM	[] Take picture (in microscope) after etch. [] Time permitting, measure resist thickness with Filmetrics-F50 or Filmetrics-F20
2.4	Solvent clean	Rinse with acetone, IPA. Blow dry N2	Nano/Solvent-L06 or Solvent-Clean-U06	2025/03/11 PM	[] Take pictures in microscope (particularly around litho test structures) after clean hot NMP 5 min, acetone, IPA (NO sonication) probe station A1 { 51 sq: $\frac{100 \text{ mV}}{85 \mu\text{A}} = 23 \Omega/\square$?? it was 48 before 101 sq: $\frac{100 \text{ mV}}{43.6 \mu\text{A}} = 22.5 \Omega/\square$ nice and linear D5 { 51 sq: $\frac{100 \text{ mV}}{78.5 \mu\text{A}} = 24.9 \Omega/\square$ 101 sq: $\frac{100 \text{ mV}}{41.2 \mu\text{A}} = 24.0 \Omega/\square$  








Part 3: Semiconducting channel
Sputter ITO and wet etch to form semiconducting mesa



#	Steps	Process steps	Tool	Date/Time	Checklist																				
3.1	Sputter channel	Change target 3 to ITO Sputter 3nm of ITO. RF 100W: Ar 31.5sccm, O2 3.5sccm, 3mTorr, 120s 5 min 200 W presputter to clean target Note: Gun #3 angle at 0.5, 14	Nano/Sputter-AJA-LL	2025/03/11 PM	<ul style="list-style-type: none"> [] Take picture pre-deposition [] Record chamber base pressure [] Measure dep rate with QCM (#20 for ITO). [] Record P,V for spark, presputter, and sputter [] Take picture post-deposition <p>base P : 18e-6 Torr</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>strike</td> <td>ramp</td> <td>predepos</td> <td>dep</td> <td>gas</td> </tr> <tr> <td>W</td> <td>2.96</td> <td>1.6</td> <td>2.96</td> <td>2.2</td> </tr> <tr> <td>V</td> <td>4.6</td> <td>2.8</td> <td>0</td> <td>6</td> </tr> <tr> <td></td> <td>0.00</td> <td>4.00</td> <td></td> <td></td> </tr> </table> <p>dep time 120 s (3 nm) (3:00 layer time)</p> 	strike	ramp	predepos	dep	gas	W	2.96	1.6	2.96	2.2	V	4.6	2.8	0	6		0.00	4.00		
strike	ramp	predepos	dep	gas																					
W	2.96	1.6	2.96	2.2																					
V	4.6	2.8	0	6																					
	0.00	4.00																							
3.2	Photolithography [Layer 4]	AZ3312 1um recipe: MLA: 130MJ 405nm. Invert design HPO1,3 > DEV7 HPO2,4 Develop in picoTrack: AZ726_spry_60sec. Min ITO width = 2 um A2 726 - spry - 60s - nobb Min spacing = 2 um ↳ recipe mode: set HPO1, HPO3 115C if not mark → go back do the same (bypass post-exposure) → the only hard task if looks good always	Nano/CoatDevelop-picoTrack, MLA150-AirAF or OptAF or WaferOnly	2025/03/12 AM	<ul style="list-style-type: none"> [] Record rotation, scaling, shearing [] Record dose, defocus [] Record layer # from GDS file [] Take picture in microscope after developing, checking alignment <p>PEB 115C , 30s CP 20s Dev spray 60s ↓ looks good in microscope J HB 120 C , 60s excellent alignment</p> 																				
3.3	Wet etch ITO	Prepare 1:10 HCl:H2O by mixing 120mL 36% HCl and 1.2L DI water. Dip cassette with wafers into diluted HCl for 24 seconds (19 s timer) or until color change completes. No agitation. Rinse in DI water. N2 dry	Nano/Acid-Extended-U07 (IGZO) or Nano/Acid-Etch-General-U10/L06 (ITO)	2025/03/12 PM	<ul style="list-style-type: none"> [] Take picture before etch [] Take picture (in microscope) after etch <p>pre-etch ↓</p>  <p>postetch ↓</p>  <p>120 mL : 1.2L (fresh HCl) 2x 19s timer (~ 45s total) ↓ didn't see color change, but forgot that Al2O3 made water blue already...</p>																				
3.5	Solvent resist strip	Soak in hot NMP for 10 minutes, then sonicate for 1 min. Rinse with acetone, IPA. Blow dry N2 30	Nano/Solvent-L06	2025/03/12 PM	<ul style="list-style-type: none"> [] Inspect in microscope after strip, checking for residual resist <p>heats up to 200C after ~10 min ramp + 30 min, then acetone, IPA looks great!</p> 																				
3.6	Plasma ash resist strip	Remove any residual resist with O2 plasma slow-strip-10min (Barrel-Thierry)	Nano/Asher-Barrel-Thierry or TergeoPro-Strip or Chuck-ESI	2025/03/12 PM	<ul style="list-style-type: none"> [] Inspect in microscope after clean  																				

Part 4: Metal source/drain contacts
Liftoff evaporated Ni to form source and drain contacts



#	Steps	Process steps	Tool	Date/Time	Checklist
4.1	Photolithography [Layer 3]	nLOF2020 2um recipe MLA: 340mJ/405nm, 0 defocus. Invert design Develop in picoTrack: AZ726_spry_60sec_NOHB. <i>375 nm!</i>	Nano/CoatDevelop-picoTrack, MLA150-AirAF or OptAF	2025/03/12 PM	<ul style="list-style-type: none"> [] Record rotation, scaling, shearing [] Record dose, defocus [] Record layer # from GDS file [] Take picture in microscope after developing, checking alignment <p>v12 , L3 , invert 340 mJ, 375 nm 0 defoc rotation: -2.753 mRad scale: 1.0/1.0 dwell: 0.004 mRad</p>  
4.1	Evaporate Ni	30 nm Ni (or more)	Nano/EBeam-Temescal-FC2800 or EBeam-Temescal-LL	2025/03/13 AM	<ul style="list-style-type: none"> [] Take picture of wafer pre-deposition [] Record chamber base pressure [] Take picture of wafer post-deposition [] Measure Rsheet with 4-point probe <p>10 nm Ni, 30 nm Au (0.11 Å) ↓ (0.31 Å) ↓ pocket 6 pocket 3</p> <p>base pressure 1.1 e-6 Torr</p> <p>Ni thickness: 0.1021 Å Au thickness: 0.3021 Å</p>  
4.4	Liftoff resist	Soak in hot NMP for 30 minutes, then sonicate for 1 min. Rinse with acetone, IPA. Blow dry N2	Nano/Liftoff-L08	2025/03/13 AM	<ul style="list-style-type: none"> [] Take picture in microscope (particularly around litho test structures) before liftoff [] Take picture in microscope (particularly around litho test structures) after liftoff <p>7:52 am into hot NMP 8:32 am out of hot NMP</p>  
4.5	Etch Al2O3 SKIP IF DQING OPTIONAL PART 2B	AZ435 MIF, 700s (slight overetch for 150A at 0.23A/s). dip in DI 3 times, rinse under flowing DI. Dry with N2 gun.	Nano/Develop-L08		 

#	Steps	Process steps	Tool	Date/Time	Checklist
4.6	Electrical testing	Measure leakage, breakdown voltage of MIM capacitors. Measure resistance of Ni resistors on top metal layer.	Nano/Probstation-Summit-11000		

Remarks/measurement results

Resistivity @ 0V

AI: 6.7 MΩ /□ ?	w1 res w/pads AI { 51 Ω : $\frac{5V}{1.55\mu A} \rightarrow 23.06 \Omega /□$	gated TLM? → via design seems messed up, no effect
B1: 5.0 MΩ /□ ?	101 Ω : $\frac{5V}{2.22\mu A} \rightarrow 22.01 \Omega /□$	bottom TLM → weird characteristic; chuck gating has an effect
G1: 9.3 MΩ /□	w2 res AI { 51 Ω : $\frac{5V}{10.1\mu A} \rightarrow 2.4 \Omega /□$	top TLM → nothing; seems completely open ?? (AI)
H1: 10.6 MΩ /□	101 Ω : $\frac{5V}{22.5\mu A} \rightarrow 2.2 \Omega /□$	→ D4 TLM seems better
H2: 9.3 MΩ /□		
A2: 30 MΩ /□		
A7: ?? MΩ /□ (4.6?)	via crossing AI - 2 $\frac{100mV}{1.56\mu A}$ ✓	transistors D4 w:100, L=1, L _o =5 no field effect } forgot to plug SWU
A8: 66 MΩ /□ ??	A1 - 4 $\frac{100mV}{3.05\mu A}$ ✓	B2 w:100, L=2, L _o =5 " } back in !!!!!
↑ can't seem to get good data	AI - 10 $\frac{100mV}{257\mu A}$ ✓	
	AI - 20 $\frac{100mV}{145\mu A}$ ✓	AI_100_2_2 breakdown
	AI - 50 $\frac{100mV}{79.7\mu A}$ ✓	

AFM

mesa 0001 → no thickness test structure
mesa 0002 → transistor 5/2/2
0003 → same but rotated 90°
mesa 0004 → repeat of 0001 but with appropriate spin
0005